

PTO Safety


MANUAL



PTO Safety Check List

- ✓ PTO Shaft must be completely enclosed within the Guard
- ✓ Tractor "U" Guard must be fitted
- ✓ Machine "O" Guard must be fitted
- ✓ Chains must be fitted to both end of PTO Guard
- ✓ Grease PTO Guards Regularly
- ✓ Switch off engine before handling PTO
- ✓ Ensure PTO is cut to correct length to suit tractor
- ✓ Ensure Lift Arms of Tractor are clear of PTO
- ✓ When unhitched PTO should be placed on a stand to minimise risk of Damage to covers
- ✓ Refer to operators manual for correct PTO speeds

Key Safety Components



Fully Covered PTO

Implement "O" Guard



Take home messages

- Is your machine safe?
- Have you all Guards in place?

